



How to Read Your Advanced Meter

Horizon Power has installed advanced electronic meters at all customer properties across regional and remote WA. These meters are read and monitored remotely and meet standards approved by the National Measurement Institute of Australia.

Because your meter is read automatically, you don't need a physical meter read at your property. However, you might still want to check your meter to:

- Monitor your electricity use
- See how much energy you've exported to the network
- Work out your renewable energy buyback return.

There are several types of advanced meters, including:

- Single phase electronic meter
- Three phase electronic meter
- Plug-in electronic meter

A step-by-step guide for each type is provided overleaf

*Owned by the
people of WA*

HORIZON
POWER

Single Phase and Three Phase Electronic Meters



**Landis & Gyr
U1300**



**Landis & Gyr
U3300/U3400**



**Landis & Gyr
E350/U3400**

These meters have different screens that either rotate automatically every five seconds or can be scrolled manually by pressing Button 1 on the meter.

The number in the top right corner of the display tells you which 'register' you're viewing. The registers displayed are dependent on the meter program.

Brief explanation of each screen:

- Time
- Date
- 07 – KWH consumed total
- 47 – KWH net generated total
- 48 –KWH net generated peak time
- 49 –KWH net generated off peak time
- LCD display test

Plug-in Electronic Meter



EDM MK7C

The plug-in meter automatically rotates through its screens every five seconds. You can also scroll manually using the Select button.

The number in the top right corner of the display tells you which 'register' you're viewing. The registers displayed are dependent on the meter program.

Brief explanation of each screen:

- Time
- Date
- 07 – KWH consumed total
- 47 – KWH net generated total
- 48 –KWH net generated peak time
- 49 –KWH net generated off peak time
- dcon 3 – connection status indicating meter is energised
- LCD display test

Need help?

If you have any questions, contact your local Horizon Power team:

metering.services@horizonpower.com.au
1800 267 926

or visit horizonpower.com.au.

This document is available in alternate formats on request

Interpreter service: 13 14 50

TTY: 133 677